



SELECTABLE MICROPHONE MUTING SWITCH

APPLICATION INFORMATION







PASSES PHANTOM POWER

Push-to-Talk: Latching



MUTE MODE CONDITION PUSH TO TALK **SWITCH**



Actuate Switch to Route Signal thru Output

Actuate Switch Again to Mute Signal thru Output

CONTROLS:

MIC INPUT: Female 3-pin XLR-type connector accepts input

from any balanced or floating low impedance (150 ohm nominal) microphone or similar signal source.

DIRECT OUTPUT: Male 3-pin XLR-type connector provides output to

sound system inputs.

ON/OFF: Mini toggle switch turns power to unit on and off.

+9V: Receptacle for 3.5mm plug of AC power supply.

ACTIVATION SWITCH: Switch selects the route or condition of the

microphone signal. It will either mute the signal or

allow it to pass to the output.

STATUS LIGHT: Color of light indicates path of microphone signal.

> Green light indicates microphone is routed to the Direct Out. Red light indicates that the microphone

signal is muted.

DIP SWITCHES: A set of three dip switches allow selection between

latching/momentary latch action, push-to-talk/ push-to-mute push button action, and ground/lift. The MODE switch is inactive. The unit is set to MUTE

MODE at the factory.

Push-to-Mute: Latching



MODE **SWITCH**

MUTE CONDITION PUSH TO MUTE LATCHING



to Mute Signal thru Output


Actuate Switch Again to Route Signal thru Output

Push-to-Talk: Momentary



MODE **SWITCH**

MUTE CONDITION PUSH TO TALK MOMENTARY



to Route Signal thru Output


to Mute Signal thru Output

Push-to-Mute: Momentary



MODE CONDITION

MUTE PUSH TO MUTE MOMENTARY



to Mute Signal to Output

to Route Signal thru Output




NOTES:

- For safety reasons, all equipment with 3-wire AC line cords should be connected to properly grounded receptacles.
- Microphones require a ground connection somewhere in the signal path. For this reason it is suggested that a properly grounded mixer always be connected to the DIRECT OUTPUT.
- Units receiving inputs from AC-line-powered sources such as keyboards or stage amplification should have their GND/LIFT switches set to LIFT and the source equipment line cords properly connected to grounded 3-wire receptacles whenever possible. (See note 1).

SETTINGS:


- 1. Latch Action (LCH)
 - Latching
 - ☐ Momentary
- 2. Push Action (PUSH)
 - Push To Talk
 - ☐ Push To Mute
- 3. Mode (MODE)
 - Set to Mute Mode
- 4. Ground Lift
 - Ground
 - ☐ Lift





PRO CO MODEL: CDPM Power Mute

4.062" D x 3.218" W x 2.250" H DIMENSIONS:

103.2mm D x 81.7mm W x 57.2mm H WFIGHT: 1.00 lb / .45 kg SHIPPING WEIGHT: 2.00 lb / .91 kg







Other TradeTools™ Products from Pro Co

Audio/Video Interface Unit AV1B

AVP1 Wallplate Format Audio/Video Interface Unit

AVP1V Wallplate Format Audio/Video Interface Unit with Input Level Control

CB1 Direct Box

D_B1 Professional Direct Box DB2 Professional Stereo Direct Box DB4A Rackmount Quad Direct Box **Professional Active Direct Box** DBA1

HJ4P Professional Stereo headphone Junction Box

HJ6 **Headphone Junction Box** iFace Portable Audio Player Interface Universal Audio Gateway iGate

Wallplate Format Portable Audio Player Interface iPlate iRack Rackmount Portable Audio Player Interface

IT1 **Isolation Transformer Unit**

IT4A Rackmount Ouad Isolation Transformer Unit IT8A Rackmount 8-ch. Isolation Transformer Unit LS82 Rackmount 8-ch. 1:2 Line Level Splitter

MC2 Microphone Combiner MS2 1:2 Microphone Splitter

MS3 1:3 Microphone Splitter

MS42A Rackmount Quad 1:2 Microphone Splitter MS43A Rackmount Quad 1:3 Microphone Splitter MS82 Rackmount 8-ch. 1:2 Microphone Splitter

MS82P Rackmount 8-ch. 1:2 Phantom Power Microphone Splitter

MS83 Rackmount 8-ch. 1:3 Microphone Splitter

MS83P Rackmount 8-ch. 1:3 Phantom Power Microphone Splitter

Panic Button Multi-Mode Mic A/B & Muting Unit Power Mute Multi-Mode Mic Muting Switch Short Stop Momentary Press-to-Mute Mic Switch

Sign Off Latching Mic Muting Switch

SAS1 Sports Announcer's Switch (Press-to-Talk)

SAS2 Sports Announcer's Switch (Press-to-Talk) with Gooseneck SAS3 Sports Announcer's Switch (Press-to-Talk) with wired Gooseneck

Switch Witch Rackmount 4-ch. Powered Monitor Selector

... plus our full line of audio cabling, snakes!

