



### Components


1. EVO-E Rechargeable Wireless Headset Mic
2. EVO-PREC Rechargeable Wireless Receiver
3. Headset Windscreen
4. 1/4" to 1/8" Cable
5. USB Power Adapter
6. Dual USB-C Charging Cable
7. Protective Neoprene Pouch
8. Quick Start Guide





### Setup


- 1 


Use the dual USB cable and USB power supply to charge the headset and receiver.
- 2 


Using the 1/8" to 1/4" cable, connect the receiver to an input on your sound system/mixer.
- 3 


Use the output, either mic or line level, that is appropriate for your sound system input.
- 4 


The included adhesive backed hook and loop fastener can be used to attach the receiver as needed.
- 5 


Turn on the receiver by pressing the power button.
- 6 


To select a channel press and hold either the up or down button until CHA displays with the current channel. Now use the up or down buttons to change the channel.
- 7 

Adjust the volume using Up and Down buttons. If you previously adjusted the channel setting wait about 5 seconds for the receiver to default back to volume
- 8 

Select the channel matching the receiver using the channel select button.
- 9 

Turn on the headset by pressing the power button.
- 10 

Put on the headset, the strap can be used to adjust the fit.
- 11 

Position the microphone at the corner of the mouth.
- 12 

Turn up the volume on the sound system channel to the level needed.

**UHF  
BAND**



SUPERIOR SOUND  
FOR YOU



# EVO-E

Water & Sweat Resistant Headset Mic &  
Pocket-Sized Wireless Receiver Mic System

## Quick Start Guide



## FAQ

- 1. Q. How long does a charge last?**  
A. About 4 hours
  
- 2. Q. Can I use the USB cable to give the Receiver continuous power?**  
A. Yes, however if power is lost you will need to press the power button again.
  
- 3. Q. How do I know which output to use?**  
A. If you do not know if your input is mic level or line level, start with the mic level output. If you are unable to get acceptable level/volume, move to the line level output.



# BE HEARD™

## Other Helpful Sources

EVO-E Product Page

EVO-E Quick Start  
(PDF Download)

YouTube Channel

Specifications subject to change without notice.

601 E. Pawnee Wichita, KS 67211 316. 263.2852 FAX 316.263.0642 [www.galaxyaudio.com](http://www.galaxyaudio.com)  
Distributed in Canada by Audio Distributors International (ADI) 1275 Newton, unit 6 Boucherville, QC J4B 5H2 Canada  
450.449.8177 FAX 450.449.8180

Printed in China V20220720



BY SUPERIOR SOUND FOR YOU