



PURERESONANCEAUDIO[®]

G3 PENDANT SPEAKER COVER KIT

INSTALLATION MANUAL



Caution: Please read these instructions carefully before operating.
Damage caused by misuse is not covered by the warranty.

WARNING!

IMPORTANT SAFETY INSTRUCTIONS

*****THIS PRODUCT MUST BE INSTALLED BY A QUALIFIED TECHNICIAN. THE PROVIDED INSTALLATION HARDWARE MUST BE USED TO INSTALL THIS PRODUCT. SPEAKER UNIT MUST BE ATTACHED BY A SAFETY CABLE!*****

NOTE: BEFORE BEGINNING INSTALLATION BE SURE TO TAKE PRECISE MEASUREMENTS.

INTRODUCTION

DESCRIPTION


The Pure Resonance Audio C3 Pendant Speaker Cover Kit is designed for hanging the C3 3" Micro speaker in exposed open plenum ceilings, raked ceilings, and other contemporary open architectures. The included 4 conductor 20 gauge speaker cable with integrated multi-strand steel stress-relief safety cable and loop nut cinch is 12 feet long and designed to suspend the pendant mount hanging speaker from the ceiling while providing the necessary wiring.

SPECIFICATIONS

| | |
|----------------------|---|
| Speaker Cable | 4 conductor 20 ga. With multi-strand steel safety cable and loop nut cinch |
| Speaker Cable Length | 12' (3.6 m) |
| Height | 7" (177.8 mm) |
| Height with nut | 7.125" (180.975 mm) |
| Front | 4.75" (120.65 mm) |
| Rear | 3.125" (79.375 mm) |
| Weight | 1.13 lbs (0.513 kg) |

PACKLIST

Ensure that you have received all parts according to the component checklist prior to installation.



Pendant Speaker Cover
with Collet Nut



Speaker Wire with
Safety Cable &
Loop Nut Cinch




Installation Manual

INSTALLATION


1. Unpack the C3 speaker and the pendant speaker cover and speaker cable with integrated safety cable and loop nut cinch.
2. Remove the easy-mounting ring included on the C3 speaker.
3. Unscrew the gray collet nut on the rear of the pendant speaker cover and thread the provided speaker cable through the collet nut and into the back of the pendant cover.
4. Connect the speaker wire to the back of the C3 speaker. (If daisy-chaining, connect all 4 speaker cables.)
5. Screw the C3 speaker unit into the pendant speaker cover until fully tightened.
6. Screw down the plastic collet nut on the back of the pendant speaker cover.
7. Securely attach the safety cable.

DIMENSIONS

PENDANT SPEAKER COVER



SPEAKER WIRE WITH SAFETY CABLE



SERVICE

Ensure the problem is not related to operator error or system devices that are external to this unit. Information provided in the troubleshooting portion of this manual may help with this process. Once it is certain that the problem is related to the product, contact your warranty provider as described in the warranty section of this manual.

LIMITED WARRANTY

PRO ACOUSTICS, LLC. ("PRO ACOUSTICS") warrants this product to the original purchaser to be free from defects in materials and workmanship (subject to the terms set forth below), for the following periods from the date of purchase.

THIS WARRANTY COVERS THE LISTED PRODUCTS AGAINST DEFECTS IN MATERIALS OR WORKMANSHIP FOR THE FOLLOWING PERIOD

| Warranty Terms | |
|--------------------------|---------|
| Speakers | 2 Years |
| Amplifiers & Electronics | 1 Year |
| Microphones | 1 Year |
| Accessories | 1 Year |

PRO ACOUSTICS will repair or replace (at PRO ACOUSTICS's option) this product or any defective parts (excluding electronics and amplifiers) in this product.

Your authorized PRO ACOUSTICS dealer will inspect the product and, if your dealer is not equipped to perform the repair of your PRO ACOUSTICS product, they will replace your product or return it to PRO ACOUSTICS for repair, at their discretion. Proof of purchase in the form of a bill of sale or receipted invoice, which is evidence that this product is within the warranty period, must be presented to obtain warranty service.

This warranty is invalid if the factory applied serial number has been altered or removed from this product. This warranty is invalid if this product was not purchased from a PRO ACOUSTICS authorized dealer. Cosmetic damage or damage due to accident, acts of God, misuse, abuse, negligence, commercial use, or modification of, or to any part of, the product are not covered in this warranty. This warranty does not cover damage due to improper operation, maintenance or installation, or attempted repair by anyone other than PRO ACOUSTICS or a PRO ACOUSTICS dealer which is authorized to do PRO ACOUSTICS warranty work. Any unauthorized repairs will void this warranty.

This warranty does not cover products sold as is.

REPAIRS OR REPLACEMENTS AS PROVIDED UNDER THIS WARRANTY ARE THE EXCLUSIVE REMEDY OF THE CONSUMER/PURCHASER. PRO ACOUSTICS U.S.A. SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY LAW, THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES WHATSOEVER, INCLUDING BUT NOT LIMITED TO, THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PRACTICAL PURPOSE.

This warranty gives you specific legal rights. You may have other rights which vary from state to state.

Specifications may change without notice.

PURE RESONANCE AUDIO®
(866) 676-7804
sales@pureresonanceaudio.com
www.PureResonanceAudio.com