

Clear All Marking



Clear all of the current annotations. The app will ask you to verify that you want to proceed.

Drawing Tools



Edit the appearance of your on-screen annotations.

Line Size



Select small, medium or large

Line Color

Select the color you want to draw with.



White Board



Display a white board.

HDMI



Display the HDMI source.

USB Camera



Display the USB/Document camera.

Streaming Input



Display the content streaming from a device, such as a laptop.

Wi-Fi Pairing



Display all Presenter units within range on the Wi-Fi network. Select the one you want to connect to.

Previous Slide



Display previous presentation slide.

In order for this to work, the Pointmaker Presenter must be connected by Bluetooth to the slide presentation device. Powerpoint, Keynote or Impress presentations may be used.

Next Slide



Display next presentation slide.

See *Previous Slide* for more details.

Record



Record the presentation to a USB flash drive.

Bluetooth



Display available Bluetooth devices. Only one Bluetooth device may be connected at a time. *This icon may not appear on all devices.*

Voice Control



Activate the Voice Control Settings. For more information, see the *Voice Command Guide*.



A Division of Williams AV

info@williamssound.com

www.williamssound.com / www.pointmaker.com

800-843-3544 / INTL: +1-952-943-2252

© 2018, Williams AV, LLC TCH 030A