


Voice commands can be used from the Presenter Control app for menu navigation and annotation adjustments. Voice commands connects with Siri on Apple Devices, or Google Assistant on Android devices to provide an easy way to switch video streams, line colors, or record presentations.

Voice commands can be spoken in English, Spanish or Chinese.

Using Voice Commands

To use a voice commands:

-  Press the Voice Command button. The background of the button will turn white. When the background is white, the device is waiting for a voice command.
- Say "Presenter" (主持人/presentador) followed by the command you desire.
- If you were understood, the background of the button will turn black for a few seconds while your command is run. It will turn white again when complete. If you were not understood, the background will stay white.
- Once the background of the button is white again, you can either say another voice command, or press the button again to stop using voice commands.

Available Commands

Changing Color

To change the color of annotations, say "**Presenter...**" then the name of the color.

- blue/ 蓝色/azul
- green/绿色/ verde
- pink/粉红色/rosa
- red/ 红色/ rojo
- yellow/黄色/amarillo
- white/ 白色/blanco

Clear Screen

To clear any annotations on the screen, say "**Presenter Clear.**" (主持人清理 / presentador borrar)

Show Chalkboard

To switch to the Chalkboard, say "**Presenter Chalkboard.**" (主持人白板/ presentador pizarra)

USB Data

To use USB data, say "**Presenter USB.**" (主持人USB/presentador USB)

HDMI Data

To show HDMI streams, say "**Presenter HDMI**" (主持人HDMI/presentador HDMI)

Streaming

To start streaming from your device, say "**Presenter Stream.**" (主持人视频流/presentador stream)

Line Weight

To adjust line thickness, say "**Presenter...**" then the line weight desired.

- thin/薄字体/delgado
- medium/中号字体/medio
- thick/厚字体/grueso

Advance Slides

To go to the next slide, say "**Presenter Next Page.**" (主持人下一页/presentador siguiente página)

To go to the previous slide, say "**Presenter Previous Page.**" (主持人白板/presentador pagina anterior)

Record Presentation

To begin or end recording a presentation, say "**Presenter Record.**" (主持人记录/presentador grabar)

Saving Screenshots

To save a screenshot, say "**Presenter Save.**" (主持人存盘/presentador salvar)

Calibrating Devices

To run digitizing tablet calibration, say "**Presenter Calibrate.**" (主持人校准/presentador calibrar)

Mute Audio

To mute any audio, say "**Presenter Mute.**" (主持人静音/presentador mudo)

Volume

To raise the volume, say "**Presenter Volume Up.**" (主持人大声/presentador sube el volumen)

To lower the volume, say "**Presenter Volume Down.**" (主持人小声/presentador bajar volumen)



POINTMAKER

A Division of Williams AV

info@williamssound.com

www.williamssound.com / www.pointmaker.com

800-843-3544 / INTL: +1-952-943-2252

© 2018, Williams AV, LLC TCH 031A