WARRANTY REGISTRATION

Visit www.ultimatesupport.com for a quick and convenient process for registering your new Ultimate Support product. Warranty Registration and Proof of Purchase are required for warranty fulfilment. Full Limited Lifetime Warranty and Ultimate Protection Plus Premium Service and Support Plan details are available online under Music Gear & Instrument Stands / Customer Support.

ULTIMATE SUPPORT^M

LIMITED LIFETIME WARRANTY

Ultimate Support products are constructed of the finest materials and designed and tested to stand up to the demanding lifestyle of the touring musician, gigging DJ, and working sound engineer. In the unlikely event that a product should fail due to manufacturing defect, Ultimate Support is pleased to repair or replace that product.

Please see www.ultimatesupport.com for more information.

This warranty applies to the original purchaser only and does not include damage to the product resulting from normal wear and tear, accident, misuse, improper installation or operation, or unauthorized repair or alterations.

800.525.5628 . www.ultimatesupport.com . Copyright 2009, Ultimate Support Systems . All Rights Reserved

THE STRENGTH OF INNOVATION

Product Manual

for Ultimate Support



AMP-150

ITEM #13464







Revision 2, 03.21.09 . Product Manual Item #13464M

COMPACT, PORTABLE AMP STAND

Optimal Volume

Three tilt positions direct the amp's sound up to your ears.

Leg Lock

Legs lock open for worry-free stability of up to 75 lbs. Legs fold and lock, creating a one-piece, portable unit.


Mic Boom Attachment

Threaded top tube for mic boom attachment; no need to carry an extra mic stand.

Bult-in Inovation


Are you experiencing hearing loss or do your band members complain about your volume? Well, your recent purchase will help! With the AMP-150's three tilt positions you can tip your amp back and face it toward you, allowing you to hear the high frequencies at much lower volume levels. In addition, your sound guy will have less vocal mic bleed and better control of the FOH. End result: your band will stop threatening to unplug you!

SET-UP




STEP 1

Turn stand upside-down and locate the RED Locking Knob. Turn the Locking Knob ¼ turn counter clockwise to the open position shown above.




STEP 2

Turn the stand back to the upright position and fold all three legs down until they stop in the open position. (The legs should move freely to the open position, if they do not, make sure the Locking Knob is in the open position.) Unfold the cradle arms to the down position.




STEP 3

After all three legs are in the open position turn the RED Locking Knob ¼ turn clockwise to the closed position shown above.




STEP 4

To adjust the height of the upright tube, pull up/open the locking lever, slide out the top tube to desired height and return the locking lever to the down/closed position.



STEP 5

The angle of the stand can be adjusted by selecting one of three positions. Push in the snap button and slide the leg out. The snap button must lock into the selected hole.



STEP 6

OPTIONAL: Attach a boom to the universal threads at the top of the stand's upright tube. Adjust the boom angle for miking your amp.

2