



Remote 3 toggles between Channel A and B for conversations with either of the two groups




Remote 3

All beltpacks need to be within 200' of Remote 3
Toggle Remote can switch between channels

Set to Channel A
To speak to Channel A



Set to Channel B
To speak to Channel B



Group A

Set to Channel A



Master A

Remote 1

Remote 2



Group B

Set to Channel B



Remote 1

Master B

Remote 2

