



**WMS4500 MULTICHANNEL SETUP GUIDE**  
SCHEMATIC & PART LIST 1-32 CHANNEL



## Introduction

The following schematics will help you to easily set up multi channel systems.


**Please use the equipment that is specified in the schematics only.**

For your convenience and understanding, we've added technical information and part lists. You can use this part lists when ordering the system you require! If you need any help regarding the frequency regulations or if your particular situation doesn't allow the installation of a standard system, please do not hesitate to contact us at sales@akg.com.

All the WMS4500 systems in this document are designed with active antennas that can be used in all venues with a 20m RG58 antenna cable.


### **SRA2 B/W active directional antenna**

For venues (tour sound & installs) cover a large area (up to 150m, 500ft) like music halls, stadiums and other open air applications.



### **RA4000 B/W active omni-directional antenna**

For venues without a designated transmitter area and up to 100m/330ft (free viewing direction). Ideal for conference rooms, multi purpose halls, houses of worship etc.



# Content

<b>General Information</b>			<b>Page</b>
Receiver/Antenna Placement	Information		4
Squelch	Information		4
Intermodulation	Information		4
HUB4000Q - HiQnet System Architect	Information		5
Cable Attenuation	Information		6
PS4000 dip switch	Information		6
AB4000 dip switch	Information		6
PS4000 dip Switch Matrix	Information		7
Required Component Matrix	Information		8
Glossar	Information		9

<b>WMS System</b>	<b>Antenna Type</b>		<b>Page</b>
1 Channel	SRA2 B/W	Schematic / Part List	11
1 Channel	RA4000 B/W	Schematic / Part List	13
2 Channel no PS4000W	SRA2 B/W	Schematic / Part List	15
2 Channel no PS4000W	RA4000 B/W	Schematic / Part List	17
2 Channel no PSU4000	SRA2 B/W	Schematic / Part List	19
2 Channel no PSU4000	RA4000 B/W	Schematic / Part List	21
4 Channel no PSU4000	SRA2 B/W	Schematic / Part List	23
4 Channel no PSU4000	RA4000 B/W	Schematic / Part List	25
5 Channel no PSU4000	SRA2 B/W	Schematic / Part List	27
5 Channel no PSU4000	RA4000 B/W	Schematic / Part List	29
6 Channel no PSU4000	SRA2 B/W	Schematic / Part List	31
6 Channel no PSU4000	RA4000 B/W	Schematic / Part List	33
8 Channel no PSU4000	SRA2 B/W	Schematic / Part List	35
8 Channel no PSU4000	RA4000 B/W	Schematic / Part List	37
9 Channel no PSU4000	SRA2 B/W	Schematic / Part List	39
9 Channel no PSU4000	RA4000 B/W	Schematic / Part List	41
10 Channel	SRA2 B/W	Schematic / Part List	43
10 Channel	RA4000 B/W	Schematic / Part List	45
12 Channel	SRA2 B/W	Schematic / Part List	47
12 Channel	RA4000 B/W	Schematic / Part List	49
16 Channel	SRA2 B/W	Schematic / Part List	51
16 Channel	RA4000 B/W	Schematic / Part List	53
24 Channel	SRA2 B/W	Schematic / Part List	55
24 Channel	RA4000 B/W	Schematic / Part List	58
32 Channel	SRA2 B/W	Schematic / Part List	61
32 Channel	RA4000 B/W	Schematic / Part List	64


# Technical Information

## Wireless Basics

- Every wireless microphone system has to operate on **one** specific frequency
- Transmitter and receiver of a system need to work on the **same** frequency
- Two transmitters **cannot** be used with one receiver at the same time

## Receiver/Antenna Placement

- Direct line of sight between transmitter and receiver antenna
- Keep the receiver/antennas at least 5 ft. (1.5 m) away from all transmitters
- Keep the receiver antennas at least 5 ft. (1.5 m) away from any big metal object, wire (particularly wire mesh) or sheet metal structures, walls, ceilings, etc.
- Do not place the antennas in closed areas (behind walls)
- Place the receiver at least 5 ft. (1.5 m) away from any equipment that may emit RF radiation such as lighting racks, fluorescent lamps, digital effect units, or PCs



## Squelch

- Standard: Carrier squelch, manual
  - Operates strictly on the signal strength of the signal.
  - If received signal strength drops under the adjustable squelch threshold the audio output is muted
- Advanced: Tone Code (only WMS470/4500)
  - The audio turns on only in the presence of the correct tone code and an adequate signal strength (-100dbm)
  - Lock out of all signals except ones with the correct key.

## Intermodulation

Intermodulation is the result of two or more signals of different frequencies being mixed together, forming additional signals that are not harmonic frequencies of either.

By using more than one transmitter simultaneously at the same location, intermodulation happens in the receiver and/or transmitter. These intermodulation products are generated in the bandwidth that you are using.

To avoid intermodulating frequencies, we offer pre-calculated frequencies as presets in the SR450 and SR4500 Receiver. Please, make sure that when setting up a multi channel system, all your receivers are set to the same country preset (NAME) and group. Use the automatic channel function (auto setup) to scan for free frequencies in your venue.

## HUB 4000 Q

The HUB 4000 Q adds HiQnet functionality to an AKG wireless system (SR 4500, SST 4 and upcoming devices are supported). For large wireless systems multiple HUB 4000 Q's can be used and controlled from a single computer. With connecting the HUB 4000 Q to a HiQnet network the user is able to monitor and control an AKG wireless system from a computer running System Architect.

## HiQnet System Architect

The simple and easy to use user interface of the HUB 4000 Q plug in of System Architect allows the user to setup and configure the wireless system easy and fast. With tools like Auto Setup, Environment Scan, RF Monitor and Device Manager you have all the control over your multi channel WMS system that makes your life easier handling many RF channels.

HiQnet System Architect also allows custom configuration of custom made user interfaces which makes it a perfect tool for installed sound and tour sound applications.

Today's HiQnet system is build from flagship products from Harman Pro brands AKG Acoustics, BSS Audio, Crown International, dbx Professional, JBL Professional, Lexicon Pro, Soundcraft and Studer.


## AKG User Interface



## Features

- automatic identification of all HUB4000Q's
- Simple and easy to use channel-oriented user interface
- Fast and intuitive setup and configuration of frequency management with Auto Setup, Environment Scan and Device Manager
- Offline configuration
- Save and load your setup

## Environment Scan - Frequency Graph




## Device Manager - Frequency Management

Device Name	Type	Band var	Locate	Country	Group	Channel	Frequency	Optional	Status	Send To	Receive From	Scan
Node Name: SR SR4 LOW BAND (5 Items)												
HYNAME	SR4000	4.A	Locate	AT	1.0	2	765.000	-100dB	ONLINE	Send To	Receive From	
NDIS	SR4000	4.A	Locate	AT	1.0	2	761.200	-100dB	ONLINE	Send To	Receive From	
WLL	SR4000	4.A	Locate	AT	1.0	7	765.600	-100dB	ONLINE	Send To	Receive From	
NDCL	SR4000	4.A	Locate	AT	1.0	4	765.000	-100dB	ONLINE	Send To	Receive From	
RCTER	SR4000	4.A	Locate	AT	1.0	5	771.000	-100dB	ONLINE	Send To	Receive From	
Node Name: SR SR4 HIGH BAND (3 Items)												
GUITAR	SR4000	2	Locate	AT	1.0	1	685.000	-100dB	ONLINE	Send To	Receive From	
HYNAME	SR4000	2	Locate	AT	1.0	2	681.200	-100dB	ONLINE	Send To	Receive From	
SAR	SR4000	2	Locate	AT	1.0	2	681.800	-100dB	ONLINE	Send To	Receive From	
Node Name: SR SR4 TOP BAND (9 Items)												
JACK	SST4	7.00	Locate	US	7.A	2	505.100	20mW	ONLINE	Send To	Receive From	
CHRIS	SST4	8.00	Locate	US	8.A	2	575.100	20mW	ONLINE	Send To	Receive From	
STEVE	SST4	6.65	Locate	AT	6.A	2	835.100	20mW	ONLINE	Send To	Receive From	
ALEX	SST4	8.85	Locate	AT	8.A	2	658.900	20mW	ONLINE	Send To	Receive From	
GUIT	SR4000	2	Locate	AT	1.0	4	685.000	-100dB	ONLINE	Send To	Receive From	
BASS	SR4000	2	Locate	AT	1.0	5	691.000	-100dB	ONLINE	Send To	Receive From	
VOXS	SR4000	2	Locate	AT	1.0	6	704.800	-100dB	ONLINE	Send To	Receive From	
PERC	SR4000	2	Locate	AT	1.0	7	708.600	-100dB	ONLINE	Send To	Receive From	

## Cable Attenuation

To obtain the best sound possible, you need to have the right RF input level throughout your signal chain. Premium quality wireless systems like the WMS450/470 and WMS4500, offer you adjustable RF-level settings that guarantee to maximise operating distance even when using different cable lengths and different types of cable! For this purpose, AKG's PS4000W antenna splitter, has 3 dip switches that you'll find on the right side of its front panel, behind the AKG logo.

### RG58 Cable Attenuation (MKPS, MKA5, MKA20 antenna cable)




frequency MHz	Dämpfung dB/100m	Dämpfung dB/1m
650	-45,13	-0,45
700	-47,25	-0,47
750	-49,38	-0,49
800	-51,50	-0,52
850	-53,63	-0,54

~50dB/100m


## PS4000 dip switch

These switches reduce the input RF level of the antenna input between 0 dB and 14 dB. Levels of all antenna outputs and the cascade (link) output will be reduced.



## AB4000 dip switch

The AB4000 has a fix 17.5dB amplifier in the output stage. The dip switches reduce the input RF level of the AB4000 from 0 dB and -14 dB. AB4000 gets the DC power from the PS4000W or an ASU4000 unit via the antenna cable



# PS4000 W dip switch matrix (RG58 cable)

Antenna type & Gain  Cable type & Length	Passiv Antennas			Active Antennas	
	 1/4 wave UHF Antenna 0 dB	 RA4000 W 1 dB	 SRA2 W 4-6 dB	 RA4000 BW 17 dB	 SRA2 BW 21.5 dB
<b>MKPS</b> 0.65m / 2ft	0 dB 	0 dB 	-4 dB 		
<b>MKA 5</b> 5m / 16ft	0 dB 	0 dB 	-2 dB 		
<b>MKA 20</b> 20m / 66ft				-8 dB 	-12 dB 
<b>MKA 5 + MKA 20</b> 25m / 82ft				-6 dB 	-10 dB 
<b>2x MKA 20</b> 40m / 132ft				0 dB 	-2 dB 
<b>3x MKA 20</b> 60m / 198ft  Antenna Booster AB4000 necessary !				RA4000 BW ↓ 2x MKA 20 ↓ AB4000 0 dB  ↓ 1x MKA 20 ↓ PS4000 -4 dB 	SRA2 BW ↓ 2x MKA 20 ↓ AB4000 0 dB  ↓ 1x MKA 20 ↓ PS4000 -8 dB 
<b>4x MKA 20</b> 80m / 264ft  Antenna Booster AB4000 necessary !				RA4000 BW ↓ 2x MKA 20 ↓ AB4000 0 dB  ↓ 2x MKA 20 ↓ PS4000 0 dB 	SRA2 BW ↓ 2x MKA 20 ↓ AB4000 0 dB  ↓ 2x MKA 20 ↓ PS4000 0 dB 

You have to use these PS4000 W dip switch settings for all PS4000 W **directly connected to antennas.**

All PS4000 W connected to a PS4000 W link output (cascade) have dip switch setting ON/ON/ON (0dB)



# WMS450/470/4500 Component Matrix

WMS Receiver	2x Antennas (e.g. SRA2 B/W or RA4000 B/W) 2x MKA 20 (see PS4000W dip switch matrix) plus...								
	Antenna Components			Power Supplies			PC Monitoring with System Architect		
	PS4000	ZAPD-21	MKPS	PSU4000	AC12 500mA	AC12 2000mA	HUB4000Q	PSU4000	AC12 500mA
2	1	0	4	0	0	1	1	0	1
3	1	0	6	0	0	1	1	0	1
4	1	0	8	0	0	1	1	0	1
5	1	0	10	0	1	1	1	0	1
6	2	0	14	0	0	2	1	0	1
7	2	0	16	0	0	2	1	0	1
8	2	0	18	0	0	2	1	0	1
9	2	0	20	0	1	2	2	0	1
10	3	0	24	1	0	0	2	0	1
11	3	0	26	1	0	0	2	0	1
12	3	0	28	1	0	0	2	0	1
13	3	0	30	1	1	0	2	0	1
14	4	2	36	2	0	0	2	0	0
15	4	2	38	2	0	0	2	0	0
16	4	2	40	2	0	0	2	0	0
17	4	2	42	2	0	0	3	0	2
18	4	2	44	2	0	0	3	1	0
19	5	2	48	2	0	0	3	0	2
20	5	2	50	2	0	0	3	0	2
21	5	2	52	2	0	0	3	1	0
22	5	2	54	2	1	0	3	1	0
23	6	2	58	2	0	0	3	1	0
24	6	2	60	2	0	0	3	1	0
25	6	2	62	2	1	0	4	1	1
26	6	2	64	2	2	0	4	1	1
32	9	0	80	3	0	0	4	1	1
36	9	0	88	3	0	0	5	1	2
48	13	0	120	5	0	0	6	1	1
52	13	0	128	5	0	0	7	2	1

# Glossar




**SR4500** – WMS4500 Stationary Receiver



**PS4000W** – Power Splitter 1:4 (Distribute RF signal and DC Power)

- Splits 1 antenna to 4 receiver
- Antenna cascade(Link) output to send RF-Signal to next PS4000. Cascade max. 3 PS4000.
- If you need more than 12 channels use an ZAPD in front of the first PS4000.



**PSU4000** – Power Supply Unit with 3x 12 volt outputs (2.5A and 2A)



**SRA2 B/W** – Active Directional Antenna (21.5 dB Gain)




**RA4000 B/W** – Active Omni-directional Antenna (17 dB Gain)



**CU4000** – Charging Unit for WMS4000/4500 (2 transmitter / unit)



**ZAPD-21** – Passive Combiner 2:1 and 1:2



**ASU4000** – Antenna Supply Unit

- Supplies up to three active elements (RA4000BW, SRA2BW, AB4000)



**AB4000** – Antenna Booster

- 3.5 dB – 17.5 dB amplifier



**HUB4000Q** – Network Concentrator for 8 devices (SR4500 or SST4)

- Operate with Harman „System Architect“ software - <http://hiqnet.harmanpro.com>

## Cable

**MKPS** – 0.65m/2 feet RG58 antenna cable

**MKA5** – 5m/16ft RG58 antenna cable

**MKA20** – 20/66ft RG58 antenna cable

**0110E01890** – Front mount cable

- Install ¼ wave antennas at the front of the rack



Front mount cable & ¼ wave antenna




WMS4500  
01 / 2012





# 1 Channel WMS4500 System With directional antennas & 40m antenna cable (132 feet)



**BNC I-connector**  
Available e.g. [www.rs-components.com](http://www.rs-components.com),  
Ordernumber 112-1798

**BNC I-connector**  
Available e.g. [www.rs-components.com](http://www.rs-components.com),  
Ordernumber 112-1798

## 2 HT4500 or PT4500 charging system (optional)



Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	1 channel WMS4500 system (SRA2 B/W – Antennas)		



## 1 Channel WMS4500 System with directional antennas, no PSU4000, no PS4000W

units	description	comment
1	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
1	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
2	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
4	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	ASU4000 (BNC)	Antenna Supply unit for long antenna cables (BNC connector) without AC-Adapter
3	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components


units	description	comment
1	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
1	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

### Do not forget microphone head, headset or other microphone !!

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 1 Channel WMS4500 System with omni-directional antennas & 25m antenna cable (82 feet)



Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	1 channel WMS4500 system (RA4000 B/W – Antennas)		



## 1 Channel WMS4500 System with omni-directional antennas, no PSU4000, no PS4000W

units	description	comment
1	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
1	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)
2	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	MKA 5	16.5 ft. (5m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	ASU4000 (BNC)	Antenna Supply unit for long antenna cables (BNC connector) without AC-Adapter
3	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components


units	description	comment
1	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
1	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

### Do not forget microphone head, headset or other microphone !!

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

## 2 Channel WMS4500 System With directional antennas & 40m antenna cable (132 feet)



Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	2 channel WMS4500 system (SRA2 B/W – Antennas, no PS4000, PSU4000)		



## 2 Channel WMS4500 System with directional antennas, no PSU4000, no PS4000

units	description	comment
2	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
2	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
6	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
4	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	ASU4000 (BNC)	Antenna Supply unit for long antenna cables (BNC connector) without AC-Adapter
4	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
2	ZAPD21	passive power combiner (2in 1out) or Splitter (1in 2out)
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
1	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
1	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

#### Do not forget microphone head, headset or other microphone !!

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L



## 2 Channel WMS4500 System with omni-directional antennas, no PSU4000, no PS4000

units	description	comment
2	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
2	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)
6	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	MKA 5	16.5 ft. (5m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	ASU4000 (BNC)	Antenna Supply unit for long antenna cables (BNC connector) without AC-Adapter
4	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
2	ZAPD21	passive power combiner (2in 1out) or Splitter (1in 2out)
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
1	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
1	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

#### Do not forget microphone head, headset or other microphone !!

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L



## 2 Channel WMS4500 System with directional antennas, no PSU4000

units	description	comment
2	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
2	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
1	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
4	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
1	AC12 2000mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS4000 W (you can also use a PSU4000

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
1	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
1	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 2 Channel WMS4500 System with omni-directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**

Rear View

Antenna A cascade output    Antenna A input (DC power)    Ant. B    4x Antenna A output (DC power)

Signal level adjustment

Attenuation


CLA

<input type="checkbox"/>	14 dB
<input type="checkbox"/>	12 dB
<input type="checkbox"/>	10 dB
<input type="checkbox"/>	8 dB
<input type="checkbox"/>	6 dB
<input type="checkbox"/>	4 dB
<input type="checkbox"/>	2 dB
<input type="checkbox"/>	0 dB

ON

1 2 3

dip switches behind AKG Logo



Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	2 channel WMS4500 system (RA4000 B/W – Antennas, no PSU4000)		



## 2 Channel WMS4500 System with omni-directional antennas, no PSU4000

units	description	comment
2	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
2	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
1	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)
4	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
1	AC12 2000mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS4000 W (you can also use a PSU4000)

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
1	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
1	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

#### Do not forget microphone head, headset or other microphone !!

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L



## 4 Channel WMS4500 System with directional antennas, no PSU4000

units	description	comment
4	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
4	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
1	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
8	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
1	AC12 2000mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS4000 W (you can also use a PSU4000)

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
2	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
1	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, (you can also use a PSU4000 output)
2	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 4 Channel WMS4500 System with omni-directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**



**Signal level adjustment**

**Attenuation**


**CLA**

14 dB	●	●	●	●
12 dB	●	●	●	●
10 dB	●	●	●	●
8 dB	●	●	●	●
6 dB	●	●	●	●
4 dB	●	●	●	●
2 dB	●	●	●	●
0 dB	●	●	●	●

ON

1 2 3

dip switches behind AKG Logo



Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	4 channel WMS4500 system (RA4000 B/W – Antennas, no PSU4000)		



## 4 Channel WMS4500 System with omni-directional antennas, no PSU4000

units	description	comment
4	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
4	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
1	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)
8	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
1	AC12 2000mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS4000 W (you can also use a PSU4000)

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
2	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
1	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
2	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 5 Channel WMS4500 System with directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**

Rear View

Antenna A cascade output

Antenna A input (DC power)

Ant. B

4x Antenna A output (DC power)

Signal level adjustment

Attenuation

CLA

ON

1 2 3

14 dB

12 dB

10 dB

8 dB


6 dB

4 dB

2 dB

0 dB

dip switches behind AKG Logo



**6 HT4500 or PT4500 charging system (optional)**



**HUB4000Q - Network Concentrator (optional)**

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	5 channel WMS4500 system (SRA2 B/W – Antennas)		



## 5 Channel WMS4500 System with directional antennas

units	description	comment
5	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
5	HT 4500 or PT4500	Hand-held transmitter or Bodaypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
1	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
10	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
1	AC12 2000mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS4000 W (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
3	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
3	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)



**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1


PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 5 Channel WMS4500 System with omni-directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798



### 6 HT4500 or PT4500 charging system (optional)



HUB4000Q - Network Concentrator (optional)

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	5 channel WMS4500 system (RA4000 B/W – Antennas)		



## 5 Channel WMS4500 System with omni-directional antennas

units	description	comment
5	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
5	HT 4500 or PT4500	Hand-held transmitter or Bodaypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
1	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)
10	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
1	AC12 2000mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS4000 W (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
3	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
3	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 6 Channel WMS4500 System with directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**

Rear View

Antenna A cascade output  
Antenna A input (DC power)  
4x Antenna A output (DC power)

Signal level adjustment


Attenuation

CLA

ON

<input type="checkbox"/>	14 dB
<input type="checkbox"/>	12 dB
<input type="checkbox"/>	10 dB
<input type="checkbox"/>	8 dB
<input type="checkbox"/>	6 dB
<input type="checkbox"/>	4 dB
<input type="checkbox"/>	2 dB
<input type="checkbox"/>	0 dB

dip switches behind AKG Logo



**6 HT4500 or PT4500 charging system (optional)**



**HUB4000Q - Network Concentrator (optional)**

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	6 channel WMS4500 system (SRA2 B/W – Antennas)		

AKG

HARMAN

## 6 Channel WMS4500 System with directional antennas

units	description	comment
6	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
6	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
2	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
14	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	AC12 2000mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS4000 W (you can also use a PSU4000 output)

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
3	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
3	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 6 Channel WMS4500 System with omni-directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**

Rear View

Antenna A cascade output

Antenna A input (DC power)

Ant. B

4x Antenna A output (DC power)

Signal level adjustment

Attenuation

CLA

ON

1 2 3

14 dB

12 dB

10 dB

8 dB


6 dB

4 dB


2 dB

0 dB

dip switches behind AKG Logo



## 6 HT4500 or PT4500 charging system (optional)



## HUB4000Q - Network Concentrator (optional)

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	6 channel WMS4500 system (RA4000 B/W – Antennas)		



## 6 Channel WMS4500 System with omni-directional antennas

units	description	comment
6	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
6	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
2	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)
14	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	AC12 2000mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS4000 W (you can also use a PSU4000 output)

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
3	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
3	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 8 Channel WMS4500 System with directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**

Signal level adjustment

Attenuation


CLA

<input type="checkbox"/>	14 dB
<input type="checkbox"/>	12 dB
<input type="checkbox"/>	10 dB
<input type="checkbox"/>	8 dB
<input type="checkbox"/>	6 dB
<input type="checkbox"/>	4 dB
<input type="checkbox"/>	2 dB
<input type="checkbox"/>	0 dB

ON

1 2 3

dip switches behind AKG Logo



**8 HT4500 or PT4500 charging system (optional)**



**HUB4000Q - Network Concentrator (optional)**

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	8 channel WMS4500 system (SRA2 B/W – Antennas)		



## 8 Channel WMS4500 System with directional antennas

units	description	comment
8	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
8	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
2	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
18	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	AC12 2000mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS4000 W (you can also use a PSU4000 output)

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
4	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
4	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 8 Channel WMS4500 System with omni-directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**

Signal level adjustment

Attenuation


CLA

14 dB	<input type="checkbox"/>
12 dB	<input type="checkbox"/>
10 dB	<input type="checkbox"/>
8 dB	<input type="checkbox"/>
6 dB	<input type="checkbox"/>
4 dB	<input type="checkbox"/>
2 dB	<input type="checkbox"/>
0 dB	<input type="checkbox"/>


ON

1 2 3

dip switches behind AKG Logo



### 8 HT4500 or PT4500 charging system (optional)



### HUB4000Q - Network Concentrator (optional)

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	8 channel WMS4500 system (RA4000 B/W – Antennas)		



## 8 Channel WMS4500 System with omni-directional antennas

units	description	comment
8	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
8	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
2	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)
18	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	AC12 2000mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS4000 W (you can also use a PSU4000 output)

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
4	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
4	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
1	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 9 Channel WMS4500 System with directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**

Signal level adjustment

Attenuation


CLA

<input type="checkbox"/>	14 dB
<input type="checkbox"/>	12 dB
<input type="checkbox"/>	10 dB
<input type="checkbox"/>	8 dB
<input type="checkbox"/>	6 dB
<input type="checkbox"/>	4 dB
<input type="checkbox"/>	2 dB
<input type="checkbox"/>	0 dB

ON

1 2 3

dip switches behind AKG Logo



**10 HT4500 or PT4500 charging system (optional)**

 AC-CU4000 Power Supply (1.4A) — DC IN (12V/1.4A)	 AC-CU4000 Power Supply (1.4A) — DC IN (12V/1.4A)
 AC-CU4000 Power Supply (1.4A) — DC IN (12V/1.4A)	 AC-CU4000 Power Supply (1.4A) — DC IN (12V/1.4A)
 AC-CU4000 Power Supply (1.4A) — DC IN (12V/1.4A)	 AC-CU4000 Power Supply (1.4A) — DC IN (12V/1.4A)

**HUB4000Q - Network Concentrator (optional)**

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	9 channel WMS4500 system (SRA2 B/W – Antennas)		



## 9 Channel WMS4500 System with directional antennas

units	description	comment
9	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
9	HT 4500 or PT4500	Hand-held transmitter or Bodaypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
2	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
20	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	AC12 2000mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS4000 W (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
5	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
5	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
2	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
2	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 9 Channel WMS4500 System with omni-directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**


**Signal level adjustment**

**Attenuation**

14 dB
12 dB
10 dB
8 dB
6 dB
4 dB
2 dB
0 dB

CLA  
ON  
1 2 3

dip switches behind AKG Logo



**10 HT4500 or PT4500 charging system (optional)**

AC-CU4000 Power Supply (1.4A)		AC-CU4000 Power Supply (1.4A)	
AC-CU4000 Power Supply (1.4A)		AC-CU4000 Power Supply (1.4A)	
AC-CU4000 Power Supply (1.4A)		AC-CU4000 Power Supply (1.4A)	

**HUB4000Q - Network Concentrator (optional)**

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	9 channel WMS4500 system (RA4000 B/W – Antennas)		



## 9 Channel WMS4500 System with omni-directional antennas

units	description	comment
9	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
9	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
2	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)
20	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	AC12 2000mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS4000 W (you can also use a PSU4000 output)
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
5	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
5	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
2	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
2	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1


PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 10 Channel WMS4500 System with directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**

Rear View



Signal level adjustment

Attenuation


CLA

ON


1 2 3

dip switches behind AKG Logo

<input type="checkbox"/>	14 dB
<input type="checkbox"/>	12 dB
<input type="checkbox"/>	10 dB
<input type="checkbox"/>	8 dB
<input type="checkbox"/>	6 dB
<input type="checkbox"/>	4 dB
<input type="checkbox"/>	2 dB
<input type="checkbox"/>	0 dB



**10 HT4500 or PT4500 charging system (optional)**



**HUB4000Q - Network Concentrator (optional)**

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	10 channel WMS4500 system (SRA2 B/W – Antennas)		



## 10 Channel WMS4500 System with directional antennas

units	description	comment
10	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
10	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
3	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
24	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
1	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via PS4000W, Mains Cable

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
5	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
5	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
2	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
2	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 10 Channel WMS4500 System with omni-directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**

Signal level adjustment


Attenuation

CLA


ON

14 dB	12 dB	10 dB	8 dB	6 dB	4 dB	2 dB	0 dB
-------	-------	-------	------	------	------	------	------

dip switches behind AKG Logo



**10 HT4500 or PT4500 charging system (optional)**



**HUB4000Q - Network Concentrator (optional)**

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	10 channel WMS4500 system (RA4000 B/W – Antennas)		



## 10 Channel WMS4500 System with omni-directional antennas

units	description	comment
10	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
10	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
3	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)
24	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
1	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via PS4000W, Mains Cable

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
5	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
5	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
2	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
2	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1


PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 12 Channel WMS4500 System with directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**

Rear View



Signal level adjustment

Attenuation

CLA

ON

1 2 3

14 dB

12 dB

10 dB

8 dB


6 dB

4 dB

2 dB

0 dB

dip switches behind AKG Logo



**12 HT4500 or PT4500 charging system (optional)**



**HUB4000Q - Network Concentrator (optional)**

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	12 channel WMS4500 system (SRA2 B/W – Antennas)		



## 12 Channel WMS4500 System with directional antennas

units	description	comment
12	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
12	HT 4500 or PT4500	Hand-held transmitter or Bodaypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
3	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
28	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
1	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via PS4000W, Mains Cable

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
6	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
6	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
2	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
2	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L



# 12 Channel WMS4500 System with omni-directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798


### PS4000W – Power Splitter



### Signal level adjustment



### 12 HT4500 or PT4500 charging system (optional)



### HUB4000Q - Network Concentrator (optional)

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	12 channel WMS4500 system (RA4000 B/W – Antennas)		



## 12 Channel WMS4500 System with omni-directional antennas

units	description	comment
12	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
12	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
3	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)
28	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
1	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via PS4000W, Mains Cable

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components

units	description	comment
6	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
6	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
2	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.
2	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 16 Channel WMS4500 System with directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798

**PS4000W – Power Splitter**

Rear View

Antenna A cascade output      Ant. B  
Antenna A input (DC power)      4x Antenna A output (DC power)

**Signal level adjustment**

Attenuation


14 dB
12 dB
10 dB
8 dB
6 dB
4 dB
2 dB
0 dB

CLA

ON

1 2 3

dip switches behind AKG Logo



**16 HT4500 or PT4500 charging system (optional)**



**HUB4000Q - Network Concentrator (optional)**

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	16 channel WMS4500 system (SRA2 B/W – Antennas)		



## 16 Channel WMS4500 System with directional antennas

units	description	comment
16	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
16	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
4	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
40	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via PS4000W, Mains Cable
2	ZAPD21	passive power combiner (2in 1out) or Splitter (1in 2out)

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components


units	description	comment
8	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
8	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
2	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 16 Channel WMS4500 System with omni-directional antennas & 20m antenna cable (66 feet)



**PS4000W – Power Splitter**

Rear View

Antenna A cascade output    Ant. B  
Antenna A input (DC power)    4x Antenna A output (DC power)

**Signal level adjustment**

**Attenuation**

14 dB
12 dB
10 dB
8 dB
6 dB
4 dB
2 dB
0 dB

CLA

ON

1 2 3

dip switches behind AKG Logo

**16 HT4500 or PT4500 charging system (optional)**



**HUB4000Q - Network Concentrator (optional)**

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	16 channel WMS4500 system (RA4000 B/W – Antennas)		



## 16 Channel WMS4500 System with omni-directional antennas

units	description	comment
16	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
16	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
4	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)
40	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via PS4000W, Mains Cable
2	ZAPD21	passive power combiner (2in 1out) or Splitter (1in 2out)

### Optional Components

units	description	comment
8	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
8	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
2	AC12 500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)
2	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)


#### Do not forget microphone head, headset or other microphone !!

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 24 Channel WMS4500 System with directional antennas & 20(40)m antenna cable (66 or 132 feet)

40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798




HUB4000Q - Network Concentrator (optional)

Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	24 channel WMS4500 system (SRA2 B/W - Antennas)		




## 24 Channel WMS4500 Charging System



If you don't want to use PSU4000 for optional components, you can also use 12x AC-CU4000 Power Supply for CU4000's and 3x AC12 Power Supply for the HUB4000Q's

### PS4000W Technical Information



Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	24 channel WMS4500 charging system		



## 24 Channel WMS4500 System with directional antennas

units	description	comment
24	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
24	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
6	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
60	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via PS4000W, Mains Cable
2	ZAPD21	passive power combiner (2in 1out) or Splitter (1in 2out)

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)

### Optional Components


units	description	comment
12	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
5	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via PS4000W, Mains Cable
3	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 24 Channel WMS4500 System with omni-directional antennas & 20m antenna cable (66 feet)




Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	24 channel WMS4500 system (RA4000 B/W – Antennas)		




HUB4000Q - Network Concentrator (optional)

## 24 Channel WMS4500 Charging System



If you don't want to use PSU4000 for optional components, you can also use 12x AC-CU4000 Power Supply for CU4000's and 3x AC12 Power Supply for the HUB4000Q's

### PS4000W Technical Information



Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	24 channel WMS4500 charging system		



## 24 Channel WMS4500 System with omni-directional antennas

units	description	comment
24	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
24	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
6	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)
60	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via PS4000W, Mains Cable
2	ZAPD21	passive power combiner (2in 1out) or Splitter (1in 2out)

### Optional Components

units	description	comment
12	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
5	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via PS4000W, Mains Cable
3	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)


#### Do not forget microphone head, headset or other microphone !!

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1


PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L

# 32 Channel WMS4500 System with directional antennas & 20(40)m antenna cable (66 or 132 feet)


40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798



Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	32 channel WMS4500 system (SRA2 B/W – Antennas)		




AC12 Power Supply (500mA) → To HUB4000Q DC IN




HUB4000Q - Network Concentrator (optional)

# 32 Channel WMS4500 Charging System



If you don't want to use PSU4000 for optional components, you can also use 16x AC-CU4000 Power Supply for CU4000's and 8x AC12 Power Supply for the HUB4000Q's and HPA4000's

## PS4000W Technical Information



Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	32 channel WMS4500 charging system		



## 32 Channel WMS4500 System with directional antennas


units	description	comment
32	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit
32	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!
9	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter
2	SRA 2 B/W	External directional active "paddle" antenna with amplifier (2 req.)
80	MK PS	Connecting cable for PS to SR 2.15ft (65cm)
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
3	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via PS4000W, Mains Cable

Additional parts for 40m(132feet) Antenna Cable		
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)





### Optional Components

units	description	comment
16	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000
1	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000, PS 4000 (you can also use a PSU4000
6	PSU4000	Central Power supply unit for powering up to 3 WMS 4000 HUB 4000, HPA 4000, CU 4000 or up
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 PS 4000, ASU4000, HUB 4000, HPA 4000 or SR 4000.
4	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)

# 32 Channel WMS4500 System with omni-directional antennas & 20(40)m antenna cable (66 or 132 feet)




40m / 132 ft Version:  
2x MKA20  
BNC I-connector is necessary to link cables!  
Available e.g. www.rs-components.com,  
Ordernumber 112-1798



Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref. No.	MCS0802001
Project	32 channel WMS4500 system (SRA2 B/W - Antennas)		




AC12 Power Supply (500mA) → To HUB4000Q DC IN




HUB4000Q - Network Concentrator (optional)

## 32 Channel WMS4500 Charging System



If you don't want to use PSU4000 for optional components, you can also use 16x AC-CU4000 Power Supply for CU4000's and 8x AC12 Power Supply for the HUB4000Q's and HPA4000's

### PS4000W Technical Information



Date	15.01.2012	Revision	1.0
Designer	Wolfgang Fritz	Ref.No.	MCS0802001
Project	32 channel WMS4500 charging system		



## 32 Channel WMS4500 System with omni-directional antennas

units	description	comment	code
32	SR 4500	Half-rack receiver without AC-Adapter; (frequency range 500 to 863 MHz); 2 UHF antennas; RMU 4000 rack mounting kit	3000Z00..
32	HT 4500 or PT4500	Hand-held transmitter or Bodypack transmitter; (frequency range 500 to 863 MHz); SA 63 stand adapter; 2 AA size dry batteries Do not forget microphone head headset or other microphone !!	3001Z00.. 3002Z00..
9	PS4000 W	Wide band antenna multi coupler (4+1 out) without AC-Adapter	2996Z0008
2	RA4000 B/W	External omni-directional active dipoleantenna with amplifier (2 req.)	2632Z0030
80	MK PS	Connecting cable for PS to SR 2.15ft (65cm)	6000H0206
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58	6000H0205
3	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via PS4000W, Mains Cable	2997Z000...

Additional parts for 40m(132feet) Antenna Cable			
2	MKA 20	66 ft. (20m) Cables for connecting ext. antennas to multi-couplers (2 req.) KOAX RG58	6000H0205
2	BNC I-connector	<b>EXTERNAL !! Not available at AKG</b> - BNC I-Connector (you can buy it at <a href="http://www.rs-components.com">www.rs-components.com</a> , Ordernumber 112-1798)	

### Optional Components

units	description	comment	code
16	CU 4000	Twin charger + 2 BP 4000 for HT 4000 & PT 4000; with AC Adapter. Please specify one of the AC- CU4000	2887Z0004
1	AC12 1500mA EU/US/UK	12V AC-Adapter (EU-Version) power supply CU4000 (you can also use a PSU4000 output)	7801H000...
6	PSU4000	Central Power supply unit for powering up to three HUB4000Q, CU4000 or up to 12 receivers via	2997Z000...
1	AC12 500mA EU/US/UK	12V AC-Adapter for 1 ASU4000, AB4000, HUB4000Q or SR4500.	7801H000...
4	HUB4000 Q / none	Network concentrator without AC-Adapter; of 8 systems	2955Z0014
1	DHCP Net Switch + CAT5 Cable	<b>EXTERNAL !! Not available at AKG</b> - for 4 input to 1 output (e.g. D-Link)	

**Do not forget microphone head, headset or other microphone !!**

HT4500: e.g. D5 WL-1, D7 WL-1, C5 WL-1, C535 WL-1

PT4500: e.g. C544L, C555L, C520L, C516ML, C518ML, C519ML, HC577 WR-L, CK77 WR-L, CK99L, C411L, C417L