

## MCDT300A – Professional Desktop Meeting Microphone

---



Thank you for your purchase of the Speco Technologies MCDT300A Professional Meeting Microphone. This microphone was specially designed for use in meetings, lectures, paging, broadcasting, podcasts, etc. The microphone is constructed with a high quality condenser cartridge to ensure high sensitivity and good frequency response. Please read the following instructions carefully before use.

### OPERATION GUIDE

1. Insert two AA batteries (Not included) and connect the audio cable.
2. Lower the volume of the amplifier to zero.
3. Turn on the power switch of the amplifier and meeting microphone, and then adjust the volume of the amplifier slowly to desired level.

### \*\*\*\*CAUTION\*\*\*\*

**Keep the microphone away from any loudspeakers to avoid potentially damaging feedback. Don't tap the microphone and avoid damage to the microphone body. Don't store the microphone in exceedingly warm or moist environments.**

Capsule Type:	Condenser
Polar Pattern:	Cardioid
Frequency Response:	40~1600Hz
Sensitivity:	-42±2dB
Output Impedance:	200Ω
Power Supply:	DC3V/48V

**Replacement cable part #: MDCT300ACBL**

---

Speco Technologies is constantly developing and improving products.

We reserve the right to modify product design and specifications without notice and without incurring any obligation.

**Speco Technologies** • 200 New Highway • Amityville • NY • 11701 • [www.specotech.com](http://www.specotech.com)

Rev. 04/02/20